


Expressive Language Quick Start Guide

Components:

- A. iLs Expressive Language Amplifier
- B. Belkin Docking station – holds iPod or Nano
- C. Belkin Docking station cable – 2 ft. black cable that connects dock station to amp 3.5mm jack (back side of amp)
- D. Belkin Docking station recharger (cable and adaptor)
- E. Microphone in mic case
- F. Mic stand (3 pieces: base, 5” cylindrical stand, mic clip that holds the mic)
- G. Mic cable – connects mic to amp
- H. Optional: Olympus Voice Recorder – used for recording Mother’s Voice (VM – “Voix de Mere”)
- I. Rolls AC/DC Power adaptor cord for iLs amp



Set Up:

1. Connect mic stand: the black, 5” cylindrical stand screws onto the heavy round base, and the mic clip screws onto the cylinder. Mic then fits into the clip.
2. Connect mic cable to microphone and to “MIC INPUT” on back of iLs amp
3. Place Belkin docking station on top of amp, plug black 2” cable into back of docking station (“stereo audio+video output”) and to back of amp (“3.5mm INPUT”)
4. Connect headphones: red cable goes into “BC OUT”, black cable into “AC OUT”
5. Plug monitoring headphones into MONO jack
6. Plug power cord into back of iLs amp (“12 VDC”)
7. Turn on by pressing the “PWR” button

Amp Knobs:

MIC – controls microphone volume

BAL – controls headphone balance

3.5mm – controls iPod volume (recorded activities)

AC – controls both mic and iPod volume; rarely used except for fine tuning volume

BC – controls BC volume; for +1 BC level, set at “12:30”; for +2 level, set at 2:30

VM – controls Mother’s Voice volume

HPF button – turns 8kHz filter on (“Active”) and off (“Bypass”)

MONO – controls monitor headphone volume